

Alpine Stone™

Alpine Stone™ is a rugged paver emphasizing the character of the high mountains. It's fractured surface and battered edges give Alpine Stone™ a distinctive appearance that changes as the light moves throughout the day. Available in four sizes and several colors that complement Western Interlock Tegula Garden Wall® and Chateau Wall; Alpine Stone™ enables you to bring the look and feel of the mountain heights into the comfort of your own backyard.

Composition and Manufacture


Alpine Stone™ is made from a low moisture concrete mixture. It is made under high pressure and high frequency vibration, producing a very dense stone, low in water absorption (less than 5%) and high in compressive strength PSI (above 8000). It is designed to meet or exceed ASTM C-936 and ASTM C-67 (freeze/thaw) specifications. Alpine Stone is available in a large variety of stock colors and color blends. Custom and non-stock colors are available upon request.

“Enjoy the Durability, Beauty, Convenience and Value of The Perfect Paving System”

Applications:

- Western Interlock pavers may be used for:
- Patios • Walkways • Pool Decks • Malls • Roof Decks
 - Plazas • Courtyards • Driveways

Typical Cross Section of Concrete Paver Installation



Dimensions:

Thickness: 70mm (2 ¾")


Large Square

Width: 330mm (13")

Length: 330mm (13")

Pcs/SqFt: .85

Approx Wt: 38 lbs/pc




Large Rectangle

Width: 220mm (9")

Length: 330mm (13")

Pcs/SqFt: 1.28

Approx Wt: 26 lbs/pc




Small Square

Width: 220mm (9")

Length: 220mm (9")

Pcs/SqFt: 1.92

Approx Wt: 20 lbs/pc




Small Rectangle

Width: 110mm (4 ½")

Length: 220mm (9")

Pcs/SqFt: 3.84

Approx Wt: 9 lbs/pc



Installation:

1. Layout and excavate 6"-8" deep, 4"-6" beyond finished size. Compact sub-grade. Backfill with crushed aggregate and compact again. Assure a minimum of 1 ½" of slope in 10' of drainage. Typically 4"-6" of compacted base should be used for light vehicular and pedestrian traffic, or 6"-12" for heavy vehicular or industrial traffic.
2. Screed concrete sand or similar product on a prepared base to a uniform depth of 1".
3. Place stones on sand bed. Cutting of stones can be done with a masonry saw or a stone splitter.
4. Place edge restraint along edges to hold edge. You may use concrete, PVC edge system, treated wood or steel.
5. Compact paving stone with a vibratory plate compactor until uniformly level and true to grade. Fill joints by sweeping in sand.

Paving Stones and Retaining Wall Systems Made for the Northwest


Western Interlock, Inc. (503)623-9084
10095 Rickreall Rd. 1(800) 627-3153
Rickreall, Oregon 97371 fax (503) 623-9122




Alpine Stone™ Installation Patterns

There are many patterns you can use in the installation of paving stones. We have provided some basic patterns below. Keep in mind that Large Square, Large Rec, Small Square and Square Rec Alpine Stones™ all module together, expanding your creative options.

80% Large Rec 20% Square Linen



46% Large Rec 31% Square 23% Small Rec Step Running Bond Using Three Sizes



Random

